

## SPRING CHECKUP - Now's a good time to inspect your UV system

Routine preventative maintenance will help to ensure that your TrojanUV® system continues to operate as effectively and efficiently as possible.

**Here's a handy list of some of the tasks that we recommend doing around this time of the year:**

### System Controls & Electrical

- Inspect sealing of enclosures
- Check all electrical connections and tighten as necessary
- Confirm breakers are on, fuses in place
- Review current alarm status
- Confirm lamps and drivers are operational
- Confirm controls system is in the correct mode of operation

### Hydraulics (not applicable to TrojanUV3000®B)

- Check pump and hoses for leaks, verify the Hydraulic System Center (HSC) reservoir level
- Replace hydraulic oil filter
- Check hydraulic pump pressure
- Confirm wiping time for the sleeve cleaning system
- Confirm hydraulic system is in the correct mode of operation

### Cooling System (TrojanUV4000 only)

- Inspect coolant pumps and hoses for leaks
- Verify operating pressure
- Confirm hydraulic operation
- Verify the coolant reservoir level
- Check coolant pH and water/glycol ratio

### UV Modules

- Inspect module cables for wear or damage, particularly the connector
- Inspect lamp sockets and lamp/socket orientation
- Confirm output of UV intensity sensors
- Check that all sleeve nuts are tight and secure (not applicable to TrojanUVSigna™)
- Inspect quartz sleeves for fouling
- Inspect for moisture inside of quartz sleeves (if any moisture is found, dry and replace the sleeve O-ring)

### ActiClean Sleeve Wiping System (not applicable to TrojanUV3000B)

- Inspect and replace the wiper seals as required
- Fill the wiper collars with ActiClean® gel
- Inspect hydraulic cylinders
- Grease hydraulic cylinders (not applicable to TrojanUV4000™)

### Peripheral Equipment / Other

- Inspect / clean UVT analyzer and confirm service is up to date
- Verify low water level shutdown sensor operation
- Inspect Automatic Level Control (ALC) or Motorized Weir Gates for proper operation – perform recommended maintenance as per O&M manual
- Confirm grout/seals are intact
- Check channel cleanliness
- Inspect condition of winch, including pendant, cable, etc. (TrojanUV4000 only)

**Remember to read all user documentation before performing operations, inspections, repair, or maintenance on your UV system.**

For more information, reach out to your regional Trojan representative, or contact your Trojan Account Manager at: [info@trojanuv.com](mailto:info@trojanuv.com)

**North America:** +1-866-388-0488  
**International:** +1-519-457-2318

To learn more about the brands and affiliates of Trojan Technologies, please visit [www.trojantechnologies.com](http://www.trojantechnologies.com)